




# VX2203M

# Tlf.3171 & Videomonitor 3371 - 3471


Dipswitch S2: i ON position  eller 




## Nr. 1 i et System.




## Nr. 2 - 3 - 4 og så videre.








Tlf. nr.



















Tlf. nr.


















Tlf. nr.



Tlf.Nr.	2203	DipSwitch	Navn/Lejlighed
1	1A		
2	1B		
3	1C		
4	1D		
5	1E		
6	1F		
7	1G		
8	1H		

Tlf.Nr.	2203	DipSwitch	Navn/Lejlighed
9	2A		
10	2B		
11	2C		
12	2D		
13	2E		
14	2F		
15	2G		
16	2H		

Tlf.Nr.	2203	DipSwitch	Navn/Lejlighed
17	3A		
18	3B		
19	3C		
20	3D		
21	3E		
22	3F		
23	3G		
24	3H		

Tlf.Nr.	2203	DipSwitch	Navn/Lejlighed
25	4A		
26	4B		
27	4C		
28	4D		
29	4E		
30	4F		
31	4G		
32	4H	